



## LIST OF PARTS

1 Barrel  
2 Front Sight  
3 Front Sight Cover  
4 Rear Sight Ramp  
5 Rear Sight Base  
6 Rivet  
7 Slide  
8 Receiver  
9 Magazine Housing  
10 Magazine Housing Front Screw  
11 Magazine Housing Rear Screw  
12 Magazine Catch  
13 Magazine Catch Spring  
14 Magazine Catch Pin  
15 Sear  
16 Sear Spring  
17 Screw  
18 Washer  
19 Trigger  
20 Trigger Pin  
21 Retaining Ring (2x)  
22 Roll  
23 Pin  
24 Bolt Guide

25 Bolt  
26 Extractor  
27 Holder  
28 Extractor Spring  
29 Safety  
30 Bolt Handle  
31 Striker  
32 Striker Spring  
33 Striker Spring Support  
34 Stock  
35 Butt Plate  
36 Butt Plate Screw (2x)  
37 Sling Swivel (2x)  
38 Trigger Guard  
39 Trigger Guard Plate  
40 Trigger Guard Screw (2x)  
41 Rear Stock Screw  
42 Magazine Shell  
43 Magazine Follower  
44 Magazine Follower Spring  
45 Magazine Base  
46 Magazine Plunger  
47 Magazine Plunger Spring

### 10 Shot Magazine

48 Magazine Shell  
49 Magazine Follower  
50 Magazine Follower Spring